



RESOLUTE™ RT BOILER

GAS-FIRED




LISTED

MH27877

ANSI Z21.13b-2012
Low-Press Boiler

OWNER AND INSTALLATION MANUAL GAS HEAT EDITION

Manufactured By:
Energy Kinetics, Inc.
51 Molasses Hill Road
Lebanon, NJ 08833
(908) 735-2066
www.energykinetics.com



H

ASME certified by EKI.
Certificate plate is under
the jacket on the steel
vessel.

- INSTALLER:** HANG THIS INSTRUCTION MANUAL AND ACCESSORY INSTRUCTIONS VISIBLY NEXT TO THE BOILER USING THE SUPPLIED POUCH.
- HOMEOWNER/USER:** READ AND SAVE THIS INSTRUCTION MANUAL AND ACCESSORY INSTRUCTIONS FOR FUTURE REFERENCE.

Please Read This First

Special Attention Flags

Please pay particular attention to the following flags when you see them throughout this manual.

DANGER: Notifies you of hazards that **WILL** cause severe personal injury, death or substantial property damage.

WARNING: Notifies you of hazards that **CAN** cause severe personal injury, death or substantial property damage.

CAUTION: Notifies you of hazards that **WILL or CAN** cause minor personal injury or property damage.

NOTICE: Notifies you of special instructions on installation, operation, or maintenance that are important, but not normally related to injury or property damage hazards.

WARNING: If the information in this manual is not followed exactly, a fire or explosion may result, causing property damage, personal injury or loss of life.

WARNING: Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other gas appliance.
Provide unobstructed combustion air openings sized and located per boiler manual and applicable codes.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from an outside phone.
- Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

WARNING: Installation and service must be performed by a qualified installer, service agency or the gas supplier.
Retain this manual for use by your qualified service technician only. Should you observe unusual or abnormal operation of the burner or boiler, contact your qualified service technician immediately. Do not attempt to service or repair this product yourself.

WARNING: Have the burner/boiler started up and serviced at least once annually by a qualified service technician. Professional care is necessary to properly service your equipment and verify it is operating reliably. Failure to properly maintain the equipment could result in severe personal injury, death or substantial property damage.

WARNING: You must keep the area around the burner/boiler free from the following.

- Do not store or use gasoline or other flammable vapors or liquids near or in the same room as the burner.
- Do not use or store laundry products, paint, varnish, thinner or other such chemicals near or in the same room as the burner/boiler. These chemicals cause creation of acids in the burner, heat exchanger and vent system that can cause severe damage.
- Do not store combustible materials near or in the same room as the burner/boiler.
- Failure to comply could result in severe personal injury, death or substantial property damage due to potential fire, explosion or equipment damage from corrosive flue products.

General care and maintenance

- ☐ Please read through the information provided for you in this manual. Ask your qualified service technician to explain normal operation of your equipment.
- ☐ Daily inspect the space around the burner/boiler to verify the area is clean and free of the materials listed above.
- ☐ Periodically watch the operation of your burner/boiler through an operating cycle to verify normal operation. If you notice unusual conditions or equipment behavior, contact your qualified service technician. Follow the instructions on the next page to shut down the burner/boiler while waiting for the technician.

WARNING: Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury (exposure to hazardous materials) or loss of life. Refer to the user's information manual provided with this boiler. Installation and service must be performed by a qualified installer, service agency or the gas supplier (who must read and follow the supplied instructions before installing, servicing, or removing this boiler. This boiler contains materials that have been identified as carcinogenic, or possibly carcinogenic, to humans).

FOR YOUR SAFETY READ BEFORE OPERATING

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.


- A. This burner does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- B. Before OPERATING, smell all around the boiler area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor. See below.
- C. Use only your hand to turn the gas control knob. Never use tools. If the knob will not turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this boiler if any part has been under water. Immediately call a qualified service technician to inspect the boiler and to replace any part of the control system and any gas control, which has been under water.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

OPERATING INSTRUCTIONS

1. **STOP!** Read the safety information above.
2. Set the thermostat(s) to their lowest setting.
3. Turn off all electrical power to the burner/boiler.
4. This burner is equipped with an ignition device which automatically lights the burner.
5. Do not try to light the burner by hand.
6. Turn **Gas control knob** clockwise ↻ to **OFF**.



7. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow the safety information above. If you don't smell gas, go to the next step.
8. Turn **Gas control knob** counterclockwise ↺ to **ON**.
9. Set thermostat(s) to desired setting.
10. Turn on all electric power to the burner and boiler.
11. If the burner/boiler will not operate, follow the instructions **“TO TURN OFF GAS TO THE BURNER”** below and call your service technician or gas supplier.

TO TURN OFF GAS TO THE BURNER

1. Set thermostat(s) to their lowest setting.
2. Turn off all electric power to the burner and boiler if service is to be performed.
3. Turn **Gas control knob** clockwise ↻ to **OFF**. Do not force.

RECORD OF INSTALLATION

INSTALLER NAME: _____

INSTALLER ADDRESS: _____

INSTALLER CITY, STATE: _____

DATE INSTALLED: _____

NOTES: _____

SCOPE

This manual covers the Energy Kinetics Resolute RT gas boiler. The boiler is designed and equipped and has been tested to generate hot water in a low pressure closed loop system. The boiler is a major component of a closed loop system that can be used as a heat source for hydronic, radiant, domestic hot water, spa, and/or pool heating systems. Call Energy Kinetics to obtain piping and wiring instructions for applications, such as hydronic heating, radiant heating, domestic hot water, swimming pool heating, multiple boilers, injection loops, etc. The installer of the system is responsible for the final design of the system and for adding the balance of the needed parts to complete the system.

COMMONWEALTH OF MASSACHUSETTS

When the boiler is installed within the Commonwealth of Massachusetts:

- This product must be installed by a licensed plumber or gas fitter where required by law
- If antifreeze is used, a reduced pressure backflow preventer device shall be used

INSTALLER NOTE:

ALL INSTALLATIONS MUST BE MADE IN ACCORDANCE WITH ALL NATIONAL, STATE AND LOCAL, PLUMBING, HEATING AND ELECTRICAL CODES THAT MAY DIFFER FROM THIS MANUAL AND IN ACCORDANCE WITH THE FOLLOWING CODES, AS APPLICABLE:

N.F.P.A. No. 70: National Electrical Code

Canadian Electrical Code Part I, CSA 22.1

A.N.S.I. / N.F.P.A. No. 211: Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances

A.N.S.I. Z223.1/ N.F.P.A. No. 54: National Fuel Gas Code

Where required by the authority having jurisdiction, the installation must conform to the Standard for: ANSI/ASME CSD-1 Controls and Safety Devices for Automatically Fired Boilers

These codes are available from:

National Fire Protection Association

1 Batterymarch Park

Quincy, MA 02269-9101.

A hot water boiler installed above radiation level or as required by the Authority having jurisdiction, must be provided with a low water cutoff device.

A boiler should be installed in such a manner that, if the pressure vessel or any connection thereto should leak, the resulting flow of water will not cause damage to the area in which it is installed.

A hot water storage tank should be installed in such a manner that, if the storage tank or any connection thereto should leak, the resulting flow of water will not cause damage to the area in which it is installed.

A boiler's pressure relief valve, hot water storage tank T&P relief valve, backflow preventer, and all other devices must be piped to the nearest drain to avoid damage in the event the valve is actuated.

Make sure relief discharge pipes from all reliefs are properly placed to safely contain discharge. Make sure relief discharge pipes, such as from a boiler or a hot water storage tank, will safely contain hot water and/or boiling water. Make sure relief discharge pipes, such as from a boiler or a radiant heating system, will safely contain water treated with boiler chemicals and/or antifreeze. Reliefs include the boiler pressure relief valve, the back flow preventer discharge port, and the domestic hot water tank temperature and pressure relief valve. Any other reliefs, such as from radiant heating systems, must also follow these guidelines.

TABLE OF CONTENTS

OWNER AND INSTALLATION MANUAL	1
GAS HEAT EDITION	1
RECORD OF INSTALLATION	5
SCOPE	5
RESOLUTE RT BOILER.....	7
RECEIVING and UNPACKING	8
LOCATION and CLEARANCE	8
SMART VENT SYSTEM	9
GAS BURNER MOUNTING	10
GAS BURNER SETTINGS	10
GAS PIPING SYSTEMS	10
GENERAL ASSEMBLY	12
BOILER MOUNTING	12
PIPING	12
ZONE CONTROL	14
FILLING WITH WATER, VENTING, and PURGING	14
BOILER WATER TREATMENT	14
ANTI-FREEZE.....	14
WINTERIZING.....	15
LINE VOLTAGE WIRING DIAGRAMS	15
Five Zone Display Manager.....	17
EXPANDED ENERGY MANAGER	19
15 ZONE MANAGER INSTALLATION INSTRUCTIONS	19
HYDRONIC CONTROL SETTINGS	20
PREPARE FOR START UP	20
START UP PROCEDURE	20
The <i>AIR-FREE</i> METHOD of MEASURING CO	21
GAS BURNER OPERATION.....	22
ENERGY MANAGER OPERATION.....	23
ENERGY MANAGER CHECK.....	24
2-MINUTE ENERGY MANAGER DIAGNOSTIC.....	24
ADDITIONAL NANGER TESTS	25
DISPLAY MANAGER RETURN SENSOR (THERMISTOR) TESTING.....	26
LINE VOLTAGE RELAYS.....	26
LINE VOLTAGE.....	26
SURGE SUPPRESSION	26
TROUBLESHOOTING with the ENERGY MANAGER	27
OPERATION WITHOUT the ENERGY MANAGER.....	28
EMERGENCY HEAT WITHOUT ENERGY MANAGER or RELAY BOARD	29
TROUBLESHOOTING THE SAFETY PRESSURE SWITCHES	30
ANNUAL TUNE UP & INSPECTION	31
AMULET REPLACEMENT	33
COMBUSTION CHAMBER REPLACEMENT.....	33

RESOLUTE RT BOILER

IMPORTANT MESSAGE TO HOMEOWNER/USER: *These instructions should be carefully read and kept for future reference to gain the best performance from your Resolute RT boiler.*

CONGRATULATIONS ON YOUR PURCHASE OF THE RESOLUTE RT BOILER with its highly efficient low mass hydronic heat exchanger, the Energy Converter. It is the product of years of engineering and advanced design, which brings together in a single system all elements needed to provide efficient home heat and hot water. This operation and maintenance information has been prepared so that you may better understand and use your **Energy Kinetics Resolute RT Boiler and Heating System**.

RESOLUTE RT BOILER - PRINCIPLE OF OPERATION

Resolute RT comprises a heat source, the energy converter, circulating water, and five (or more) zones controlled by an electronic control, the **Energy Manager**.

The boiler sits cold until a thermostat calls for heat. The Energy Manager receives the call for heat and turns on the main circulator and burner. Water circulates within the boiler as it warms up to operating temperature. When ready, the zone valves open and deliver heat to the zones calling for heat. When the thermostats are satisfied, the Energy Manager turns off the burner and enters the energy recovery stage. The circulator and zone valve stay energized to deliver the heat remaining in the boiler to your home or to the domestic hot water storage tank.

When energy recovery is complete and the boiler has been cooled off, the Energy Manager turns off the system and waits for another thermostat (or tank aquastat) to call for heat. **Resolute RT** runs the burner only when you need heat and delivers that heat only where you need heat.

The Energy Converter is the product of advanced thermal engineering. It is designed with two separate passageways, nearly 15 feet long, coiled around each other. Water travels along one passageway from your home toward the center of the unit and heated gases travel from the unit center toward the chimney. This is a "forced circulation counter-flow" design and it provides very efficient transfer of heat from the burning fuel to the circulating water. The superior insulation of the boiler minimizes heat losses to the surroundings, resulting in directing heat to your home in an efficient and quiet manner.

Resolute RT has an extremely high annual efficiency (over 95% of steady state) because it runs only when your home or hot water storage tank needs heat. Energy recovery is completed at the end of each heat call, virtually eliminating off cycle losses.

Your Resolute RT holds a minimal quantity of water so it begins to supply heat in about 2 minutes. This rapid response means that your rooms can be heated quickly when cold. The Resolute RT can also provide heating of domestic water just as quickly.

A modern retention head gas burner fires into the center of Resolute RT where a high temperature, light weight stainless steel chamber provides ideal conditions for "near perfect" efficient, pollution-free combustion. Your Resolute RT is tightly sealed so all products of combustion pass only to the Smart Vent system.

The **Resolute RT** boiler is designed with a hinged front cover that allows access to the inside of the boiler for inspection and cleaning. All access for service is from the front, so the Resolute RT boiler can be placed against a wall or into a closet.

ENERGY MANAGER - PRINCIPLE OF OPERATION

The left side of the Manager is the input side, which provides 24-volt power supply and connections for thermostats. The right side is the output side, which starts the burner, circulator, zone valves or zone circulators and the domestic hot water circulator. See photo of the Manager on the cover.

Lights on the Energy Manager indicate what is calling for heat (left side) and (right side) lights indicate active zone(s), burner operation and circulator operation. These function lights are an aid in servicing. The following is a typical cycle.

1. **SYSTEM WAITING FOR A CALL:** The boiler is turned off and sits cold, waiting until a call for heat. The red power light on the Manager is glowing.
2. **CALL FOR HEAT:** A room thermostat call starts the cycle. The thermostat light on the left side will turn on for that zone.
3. **PRE-HEAT:** Output lights for the main circulator and burner turn on, the circulator starts, and the burner begins firing. The boiler water circulates through the energy converter via the bypass line, heating up the water.
4. **HEAT:** Once the boiler water has heated to 140°F (about 90 seconds), the Manager will turn on the zone output light on the right side. The zone valve will open and hot water will flow to the zone needing heat. The burner runs as long as there is a thermostat calling and as long as heat is being delivered to the zone. The burner may shut off if the return temperature exceeds 170°F/190°F (RED burner light turns off) or if the high limit temperature is exceeded (RED burner light stays on, but the high limit aquastat shuts the burner off).
5. **ANOTHER CALL FOR HEAT:** If another zone calls for heat while the burner is already running and the return temperature is above 140°F, the zone output will turn on, immediately supplying heat to the zone.

6. **MONITOR RETURN TEMPERATURE:** The Energy Manager continually senses the return temperature and will turn off the zone outputs if the return temperature drops below 120°F (130°F if Option Switch #1 is ON). With the zone outputs closed, the boiler water will quickly reheat and once the return temperature reaches 140°F (150°F if Option Switch #1 is ON), then the Energy Manager will reopen the zone valves.
7. **THERMOSTAT SATISFIED:** The thermostat light on the left side will go out. The burner light and the burner will then turn off.
8. **ENERGY RECOVERY:** The circulator and zone valve remain energized. The circulating water will remove the energy from the converter, sending the heat to the last zone that called. The energy recovery stage continues until the return temperature has dropped sufficiently or until maximum timing has been reached. The boiler is now sitting cold, waiting for the next call for heat. Maximum timing for heat recovery stage is usually set at twenty minutes for space heating zones and is fixed at five minutes for the Hot Water zone. (See *Energy Manager Option Switch Settings*).

RECEIVING and UNPACKING

TIP:

Inspect shipment upon receipt for external damage. When unpacking and uncrating, inspect each item for internal damage. Any damage found should immediately be reported to the freight carrier before installation. The receiver is responsible for following the claims procedure of the freight carrier. The freight carrier is responsible for taking prompt action on all claims. If freight cannot be inspected at the time of delivery, sign the bill of lading "Subject to Inspection" and inspect the shipment as soon as possible after receipt. Replacements for parts damaged in shipment are available upon receipt of a signed copy of a claim report (*concealed damage claims should be filed immediately against the freight carrier by the consignee*).

After unpacking, check each item against the packing list. Inspect it thoroughly for loose parts, instruction sheets and packing lists. Immediately report any missing items. It is wise to complete the installation before discarding packing material. Store all parts where they will not be damaged or lost during installation.

LOCATION and CLEARANCE


DANGER: Provide clearance to combustible surfaces in accordance with all local and national codes. Follow National Fire Protection Association Bulletin NFPA Installation of Oil Burning Equipment and all applicable codes.

Attention Receiver!

All cartons and skids must be inspected at time of delivery.

Never sign for a delivery without first inspecting your freight.

- 1) Note any carton damage on the delivery receipt; if obvious damage to the contents is visual at time of delivery you have the right to refuse the shipment.
- 2) If you're not sure how to proceed call Energy Kinetics at 1-800-735-2066 for assistance before the driver leaves.
- 3) Neither Energy Kinetics nor the trucking company is responsible for damage found after delivery or after freight is moved to the job site.



Flue: 3" Polypropylene
0" Clearance to Combustibles

Installation Clearances from Boiler Surfaces, Inches	Clearance to Combustibles	Recommended Clearance for Service
Front of boiler*	10"	20"
Left side of boiler body	0"	5"
Right side of boiler body	0"	12"
Back of boiler body	4"	4"
Top of boiler body	10"	16"
Bottom of boiler legs to floor	0"	0"
Polypropylene Venting (230° Max)	0"	0"

* Minimum recommended clearance to allow door to fully open.

Boiler Weight and Water Content	
Weight	405 lbs
Water Content	3 gallons
Air Inlet Pipe Size	3" PVC
Boiler Flue Outlet	3" Polypropylene

Resolute RT boilers come with a stand mounted at the factory which provides a convenient, solid, level and smooth foundation for the boiler. Place the unit as near to the venting location as possible allowing clearance for front cleaning and service as shown in Figure 1B

NOTICE: The stand must be **level to slightly higher at the back**, to allow for proper venting of air from the boiler.




Figure 1B - Boiler Clearance for Cleaning and Service

Burner	Dim "A"	
	W/O Silent Burner Cover	With Silent Burner Cover
Carlin EZ-Gas	14-1/2"	15-1/4"

SMART VENT SYSTEM

The Smart Vent with Dilution Air System is a complete vent system that has been specifically designed for use with Energy Kinetics' Resolute RT boiler. It uses a Dilution Air Exhaust Fan (inducer) and requires outside air for combustion air. Each part of this system works together and must be installed properly to work correctly.

Starting with combustion air, outside air must be piped directly to the factory supplied PVC air inlet tee. The PVC branch on the inlet tee is connected to the sealed air box and provides combustion air using PVC pipe and elbows supplied.

The Dilution Air Exhaust Fan (inducer) assembly is factory mounted directly on the boiler breech. The boiler pressure vessel is maintained at negative pressure by the forced draft fan. A fan proving safety switch is wired in series with the puff switch and blocked inlet switch to the 'BV' terminals on the primary control. A safety recycle or lockout occurs on the primary control if 'BV' is interrupted if operation of the forced draft fan is not proven. The system requires no draft adjustment when installed as recommended and is designed for use without any draft damper.

Combustion air is piped from the branch of the dilution air tee to the PVC male adapter on the sealed air box frame. Piping of outside air directly to the boiler is required to ensure that adequate fresh air is available for combustion and proper dilution of flue gasses. It completely isolates the boiler from the home environment, as well as greatly reducing operating noise from the boiler. A blocked air intake safety switch is wired in series with the standard Resolute RT blocked vent switch and fan prover. Burner operation will be prevented if the air inlet is blocked or if the boiler flue passage is blocked.

The Smart Vent system for the Resolute RT boiler must be installed according to the Smart Vent with Dilution Air installation manual.

WARNING: Ensure that all gear clamps on the Dilution Air adapter are tightened. After installation pull upwards on the vent to confirm a good mechanical connection. Failure to properly tighten all gear clamps can result in a failure of the venting system.

WARNING: **Sidewall venting and combustion air piping from outside the building is required.** The Energy Kinetics Smart Vent kit contains specific instructions for installation that must be followed. For length of run for intake air and for the vent connection, refer to the Smart Vent with Dilution Air installation manual. Combustion air may be supplied through PVC pipe. A Tek-screw joint allows the door to swing down when the air inlet pipe is disconnected.

GAS BURNER MOUNTING

Resolute RT boilers are shipped from the factory with the gas burner mounted. The burner flanges are designed to insert the burner head 2-3/8" into the boiler. Energy Kinetics installs a ceramic sleeve, the amulet, to protect the burner head from the heat of combustion, and then seals the air tube flange joint with a high-grade retort cement.

NOTICE: Gas burners for field installation or for field replacement should be installed according to burner manufacturer instructions, according to installation instructions below, and with consultation from Energy Kinetics for any special considerations or adjustments.

Follow these instructions for field installation or replacement of Energy Kinetics supplied burners. Start by checking electrode and flame sense rod position per manufacturer's specifications prior to assembly to unit. Test fit the amulet by inserting the amulet into the boiler opening. If the amulet doesn't easily slide into the boiler, then gently sand the outside diameter of the amulet until it will fit into the boiler opening. Test fit the amulet onto the burner head. The amulet for the Carlin burners has a smooth interior. If the amulet is a tight fit on the burner head, then slightly moisten inside the amulet with water.

Place a 3/8" bead of retort cement onto the burner head at the flange to air tube joint, and slide the (moistened) amulet over the burner head and against the flange. Ensure proper seating of the amulet by pressing the amulet onto the burner with a flat object. Leave the excess retort cement at the amulet to flange joint and the cement will provide an airtight seal of the air tube flange to the boiler face.

The Carlin amulet does not have an edge and when fully seated the amulet will be flush with the front of the Carlin burner head. If needed, trim the front edge of the amulet to be flush with the front of the burner head.

Once the amulet has been seated and trimmed, then install the burner into the boiler by carefully inserting the air tube with amulet into the boiler opening while aligning the burner flange holes with the boiler studs. Install flat washers and nuts onto the boiler studs and tighten all nuts evenly.

GAS BURNER SETTINGS

Resolute RT gas boilers are shipped from the factory preset for 100,000 Btu/Hr firing rate. The following table lists approximate settings for Carlin EZ-Gas burners based on extensive testing.

CAUTION: Final settings for a particular installation **must** be determined by using combustion test equipment and following the instructions given under "Start Up Procedure".

Input Btu/Hr	Burner Orifice Drill size		Approximate air band setting	UTL - air tube insertion length	Diffuser
	Natural Gas	Propane Gas	1 Slot	inches	
100,000*	#1 (0.228)	#16 (0.177)	15	2-3/8"	B
120,000	C (0.242)	#13 (0.189)	20	2-3/8"	B
150,000	J (0.277)	7/32 (0.219)	35	2-3/8"	B

* Default Factory Setting

GAS PIPING SYSTEMS

The boiler and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of the gas supply piping system at test pressures in excess of 1/2 psi (3.5 kPa, 14 in wc).

The boiler must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas piping system at test pressures equal to or less than 1/2 psi (3.5 kPa, 14 in wc).

A manual shut off valve and a sediment trap must be provided in the gas piping upstream of the electric combination gas valve at the boiler. The boiler and its gas connection must be tested for gas leakage before placing the boiler in operation.

Gas piping must be properly sized in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, or according to state and local codes as applicable. Gas piping must be sized to provide the maximum firing rate gas flow

for all appliances in the building. For Natural Gas installations, be sure to verify that the gas meter is properly sized for all appliances. Do not use any service 90° elbows. Use only full port shutoff valves. If in doubt, oversize the piping.

BEST PRACTICE: Always size piping based on natural gas pipe size guidelines.

The following tables provide suggested sizing for Black Iron Pipe. Be sure to add the appropriate equivalent length for every fitting and elbow used. For other types of pipe or tubing, consult NFPA 54 or the manufacturer of the pipe or tubing or your gas supplier for pipe sizing information.

For LPG, drawing up to 150,000 Btu/Hr (60 Cubic Feet per Hour)

For Natural Gas, drawing up to 150,000 Btu/Hr (140 Cubic Feet per Hour)

Natural Gas		LPG Gas	
Iron Pipe Size	Maximum Equivalent Length	Iron Pipe Size	Maximum Equivalent Length
3/4 inches	30 feet	3/4 inches	90 feet
1 inch	100 feet	1 inch	200 feet
1-1/4 inches	200 feet	1-1/4 inches	200 feet

GENERAL ASSEMBLY

Assembly of various packaged units is illustrated throughout this manual. The use of non-Energy Kinetics supplied pump, controls and accessories should follow good practices. The diagrams and locations presented in the manual are recommended.

BOILER MOUNTING

PIPING SO THE DOOR CAN OPEN: To avoid conflicts with the door opening, piping should be in accordance with **FIG. 2** or dimension D in **Fig. 1B**. The door opens and drops down to the front of the boiler. The burner and air box also need clearance when the door opens. Do not locate any piping in front of the boiler unless clearance from the door is verified. This also applies to the oil line piping and the combustion air piping. **NOTICE:** Air inlet pipe must be disconnected to allow door to swing down.

BOILER MOUNTING on BASE, FIG. 2: The boiler comes on a factory mounted base.

BOILER PITCH: The Resolute pressure vessel is manufactured level with the base. Install the boiler so it is level to slightly higher at the rear.

Premier Option:

4 Port Header Kit

3 Zone Valves (2 Wire)

Return Ball Valve and Purge

Along with Required Nipples & Fittings

Oil Filter Kit




Figure 2

PIPING


Figure 2C indicates a typical flow schematic for boiler water feeding multiple zones. Each system will vary according to job location.

Supply and return connections are 1"NPT on the Resolute RT.

Call Energy Kinetics to obtain piping and wiring instructions for alternate applications, such as hydronic heating, radiant heating, domestic hot water, swimming pool heating, multiple boilers, injection loops, etc. Figures 2C and 2D indicate general system piping arrangement and options. Piping of individual systems may vary from figures.

Some site specific heating zone piping configurations may allow heat migration, in which case a flow check(s) may be installed to prevent the gravity flow of heat.

Figure 2C
Zoning with Zone Valves



Use Energy Kinetics
Smart Thread Sealant
P/N 10-0620


ZONE CONTROL

ZONE CONTROL BY VALVE: The Resolute RT boiler is designed to provide multi-zone control of the heating system and optionally can supply domestic hot water. Energy Kinetics recommends and supplies two wire, full port, 24-volt zone valves for control of each heating zone. A system with a single heating zone still requires a zone valve to provide control for preheat of unit and to maintain minimum temperature during operation.

ZONE CONTROL BY CIRCULATOR:

Zone control by circulators requires a flow valve, circulator and 24-volt relay (EK# 10-0412-RIB or equivalent) for each zone. The main circulator and boiler bypass line are still used in these cases.

NOTICE: An additional tee must be installed into the supply **on the inlet side** of the main circulator. This tee is the supply for circulators with returns for these zones into normal return location. Call Energy Kinetics and request “Zoning with Circulators” diagram.



ZONE PURGING: Valves to isolate and purge individual zones should be installed according to good piping practices.

EXPANSION TANK SIZING: The type and size of expansion tank depends on the total system water volume. The Resolute RT contains 3 gallons of water. **NOTICE:** Sizing must consider **cold start** and **hot operation** due to system concepts of energy recovery and rapid heat up.

BOILER BYPASS LINE AND VALVE

NOTICE: Systems are piped at the factory with the boiler bypass line and bypass ball valve. The bypass valve must be at least partially open for the boiler to operate properly.

FILLING WITH WATER, VENTING, and PURGING

When piping is completed and all accessories installed the Converter and piping should be filled with water. The Converter purges itself of air when properly installed. **NOTICE: AIR VENT CAP MUST REMAIN OPEN.** Vent cap should be removed and kept in a safe location. Each zone should be purged until a steady stream of water without air passes out of purge hose. Vent all radiation.

NOTICE: DO NOT START BURNER UNTIL CONVERTER AND SYSTEM ARE FULL OF WATER. Fill to normal cold system pressure, 10 to 12 psi on pressure gauge. Before placing system in operation, carefully check for leaks throughout system. Tighten pipe joints, circulator flanges; check gaskets, etc., as needed.

BOILER WATER TREATMENT

Addition of boiler water treatment is recommended to reduce lime buildup inside the boiler. Energy Kinetics recommends addition of one quart of 8-Way Boiler Treatment per 30 gallons system water. 8-Way Boiler Treatment is recommended to treat water up to medium hardness. Call Energy Kinetics for more details about boiler water treatment and about hard water conditions.

ANTI-FREEZE

Only non-toxic antifreeze (such as Propylene Glycol) should be used if adding anti-freeze to a system that produces domestic hot water. Hard water should not be used in combination with generic antifreeze. Energy Kinetics supplies a quality inhibited Propylene Glycol anti-freeze with orange dye and an antifoam agent. 8-Way Boiler Treatment can be added to Energy Kinetics anti-freeze and is recommended in areas of medium water hardness. **NOTICE: Thoroughly clean system prior to adding antifreeze.** TSP is recommended for removing flux and other oil based compounds. Once system has been cleaned and flushed, then add antifreeze to obtain approximately a 30% by volume mixture of antifreeze in water. Call Energy Kinetics for assistance in calculating how much anti-freeze to add to system.

WINTERIZING

NOTICE: If the Resolute RT boiler may be exposed to freezing temperatures, such as a vacation home shut down for the winter, then anti-freeze should be added. When a home is winterized by draining all domestic water piping, then the Resolute RT boiler must be protected. It is not recommended to drain the boiler, because introducing air into the boiler can cause rusting inside the boiler shell and also because the Energy Converter has a spiral water passage that cannot be completely drained of water. When draining the domestic water piping system, be sure to drain the domestic side of the plate heat exchanger. If the hydronic system will not be drained, then add enough anti-freeze to protect the entire hydronic system including the boiler, piping, radiation, circulators, etc. If the hydronic system will be drained, then add shut off valves to isolate the boiler and add anti-freeze to the boiler only, as follows. Drain water from the boiler and then add anti-freeze to the boiler. Refill boiler with water and run boiler circulator through the bypass to distribute antifreeze within boiler. Propylene Glycol in water will provide the following freeze protection: 30% down to +8°F, 40% to -8°F, 50% to -27°F. Energy Kinetics recommends using 30% anti-freeze to obtain the best boiler performance. Use over 30% anti-freeze only if lower temperature freeze protection is mandatory.

Caution: Always keep the fuel supply valve shutoff if the burner is shut down for an extended period of time.


LINE VOLTAGE WIRING DIAGRAMS

WIRING and CONTROLS

The Resolute RT Heating System is furnished with controls and basic accessories as illustrated and described in this manual. Control, burner and accessory instruction sheets and system wiring diagrams should be attached to this manual for future reference.

DANGER: All wiring for installations in the United States must comply with the NEC, and any local codes. All wiring for installations in Canada must be done in accordance with the Canadian Electrical Code, Part I.

120 VAC POWER IN



ELECTRICAL CONNECTION - LINE VOLTAGE

POWER SUPPLY: 120 VOLT 60 HZ, 7.5 Amperes

Resolute RT requires 120 VAC. The supply voltage must be within 108 VAC min / 132 VAC max for reliable operation of the boiler and the Manager. An easy way to check the supply voltage is to plug a voltmeter in at the service outlet located on the side of the system junction box.

DANGER: Make All Connections with Power Off at Main Circuit Box

Figure 3A: Connect power from a separate 15 AMP fused circuit. Install 3rd wire grounding for proper bond between all electrical accessories. The system switch is included so power can be shut off at the unit for servicing.

Pigtails are provided for the line voltage power connection. Connect black pigtail to hot, white pigtail to neutral, and the green pigtail to ground.

WARNING: The junction box is wired at the factory with the service outlet always powered, even with the System Emergency Switch turned off. To have the service outlet controlled by the System Emergency Switch, move the service outlet black lead to top lug of system switch. A low water cut-off may be field installed if required by local codes and is available from Energy Kinetics.

LOW VOLTAGE WIRING

ENERGY MANAGER OPERATES ONLY ON 24 VOLTS 60 HZ POWER


WARNING: Make All Connections with Power Off at Main Circuit Box

A typical low voltage wiring diagram for the Energy Manager is shown in **Figure 4A**. Thermostats must be located on inside walls away from cold drafts, windows or heat from fireplaces, appliances or sunlight. Set thermostat heat anticipators to 0.1 amps or *Hydronic* option. Call Energy Kinetics to request alternate low voltage wiring diagrams to handle special situations such as air handler wiring, heat pump wiring, isolation relays for thermostats, and isolation relays for heat motor style zone valves or circulators, etc.

The single 24-volt/50VA transformer is suitable for the Energy Manager and five zone outputs (zone valves or relays). **NOTICE:** Additional load such as extra valves may require greater transformer capacity. To add transformers, wire in parallel as follows: wire terminal "A" on one transformer to "A" on the other. Repeat with other low voltage terminal "B". Be sure to verify 24VAC output from all transformers.

The Energy Manager is designed to heat domestic water and up to four (4) heating zones. Use Energy Kinetics supplied zone valves with two wire connections. For more than four heating zones, use Energy Kinetics expanded 10 or 15 zone Energy Manager, or call Energy Kinetics for alternatives.

LOW VOLTAGE WIRING DIAGRAM



INSTALL ENERGY MANAGER

The Energy Manager is shipped in its own protective shipping box. **NOTICE:** The option switches can be set very easily before the Manager is installed. Locate the pre-wired quick connectors fastened to the front of the junction box by two cable ties. Cut the two cable ties and discard. Fasten the Energy Manager to the junction box with the four corner screws. Slide the two quick connectors onto the Energy Manager. Label each zone on the manager, using the adhesive labels supplied.

Figure 4A


Five Zone Display Manager

The **Display Manager** is an **Energy Manager** that is equipped with an *LCD display*, and four *pushbutton keys*. With the exception of the Fuel Type (oil/gas) and Venting (chimney/inducer) options, all setup options are selected through *option screens* via the *display* and *keys*. The Fuel Type and Venting options can be viewed, but not set, in the *option screens*. These two options can only be set using the physical option switches on the bottom of the Display Manager board.


- To access the *option screens*, you must first ensure the manager is powered; if the manager is powered, the blue "PWR" LED will be on. If the blue LED is on, but the screen is not illuminated, press any *key* to wake the *display*.
- Use the UP/DOWN keys to view additional *menu screens*. Use the ENTER/ESC keys to enter/exit *submenus*. The ENTER key is also used to change *options* from the *option screens*.

How to Use Self-Guided On-Screen Prompts To Edit Options

From the *system status* screen, press the DOWN key twice, or until the *Option Setup (edit→)* menu screen is displayed. Press the ENTER key to enter into the *option screens*. From there, use the UP/DOWN keys to view each option. Use the ENTER key to change the selected option.



Setting features are self-guided through on-screen prompts



Option Switch Settings

Set option switches for Fuel type: Oil or Gas and Vent type: Chimney or Dilution Air Exhaust Fan (inducer)




Figure 4B

INSTALLATION TIPS

•Option Switches “OFF”

Display Managers are shipped with both *dip switches* “OFF” (set for an oil system with a chimney).

•Burner Restart

Thermostat short cycle protection is 25 seconds

•Manager Reset

Shutting the power off momentarily and then back on again resets the manager from the short-cycle delay or an error condition.

Display Manager Option Menu Descriptions

Fuel Type - VIEW-ONLY. Must be set using physical option switch on bottom of Manager Board

This menu can be used to **view** the setting of physical option switch one, which determines the Fuel Type setting.

Venting - VIEW-ONLY. Must be set using physical option switch on bottom of Manager Board

This menu can be used to **view** the setting of physical option switch two, which determines the Venting setting.

SmartBoost™ - Default setting is OFF

This option turns the SmartBoost function ON or OFF. While ON, if a zone has been calling for heat for 25 minutes (optionally 45 minutes), then SmartBoost kicks in to help satisfy that zone sooner by boosting the maximum return temperature to be 190°F/175°F from the standard 170°F/155°F. The boosted zone will stay at the 190°F/175°F setting for up to 25 minutes after the call is satisfied.

SmartBoost™ Delay - Default setting is 25 Minutes

This option sets the delay to either 25 minutes or 45 minutes before SmartBoost raises the maximum return temperature to be 190°F/175°F. This option only impacts boiler operation if SmartBoost is ON.

HW Zone - Default setting is Hot Water

This option will allow the hot water zone to be turned into a heating zone. While this option is set to Heating, the “Hot Water Zone” will act as a heating zone with 20 minutes of thermal purge. This change will allow the hot water zone to become a fifth heating zone, for those cases where domestic hot water isn’t required.

HW Priority - Default setting is NO

This option allows the Hot Water Zone to have priority over heating calls for 20 minutes. While this option is set to YES, the Energy Manager will ignore heating calls to the system for the first 20 minutes of a hot water call. After 20 minutes, or when the hot water call is satisfied, the system will resume providing heat to the rest of the zones.

MultiPurge™ - Default setting is OFF

This option turns the Multipurge function ON or OFF. While ON, any zones finishing in the prior 20 minute period will purge with the last zone satisfied. Setting the Purge Time for a given zone to 5 minutes prevents that zone from multi-purging.

Zone Purge Times - Default setting for each zone is 20 Minutes

This option sets either a 20 minute or 5 minute purge time for heating zones. After all zone calls have been satisfied, there may still be heat remaining in the boiler. Instead of wasting that remaining heat, the Energy Manager will keep the last calling zone (or zones, if Multipurge is ON) open to allow the heat to be purged out of the boiler and into the system. The user is able to choose to let the boiler purge for either 5 minutes or 20 minutes before closing the zone. Any zone set to 5 minutes will also have Multipurge disabled for that zone. Regardless of the selected option, the Energy Manager will always end purging and close the zone when the return temperature has dropped sufficiently.

The following types of zones are recommended to have a 5 minute purge time.

- AIR HANDLER / FAN COIL
- VERY SMALL ZONE (like an individual bathroom)
- RADIANT ZONE with STORAGE TANK

Secondary Zones - Default setting for each zone is OFF

This option allows for primary/secondary operation. If any secondary zone is enabled, the manager will assume that zone 3 controls the injection zone (IZ) and zone 4 controls the loop circulator (LC). Any zone that gets a call while set as a secondary zone will also activate the IZ and LC, when needed. Thermostats connect to zone 1 (T1) and zone 2 (T2). If the hot water zone is set as a heating zone, the HWZ will also be displayed under the Secondary Zones options.

15 Zone Manager
Figure 4C



- NOTICE:** When operating without an expanded manager, *use a 5 zone service board for the lower half*. If you do not have a service board, refer to “Operation of Boilers without Energy Manager” in the Tech Manual.

HYDRONIC CONTROL SETTINGS

Configuration	Control	Model No.	Normal Setting
Residential Boiler	Auto Reset High Limit Auto Reset LWCO Manual Reset Lock Out Temp	DualGard Model: 2450-1 Energy Kinetics PN: 10-0596	215° F Auto Reset High Limit 10° F Differential (215°/205° F)* 250° F Manual Reset Fixed Max
Commercial Boiler (conforms to CSD-1)	Auto Reset High Limit Aquastat Manual Reset LWCO Manual Reset Lock Out Temp	DualGard Model: 2450-2 Energy Kinetics PN: 10-0596-M	215° F Auto Reset High Limit 10° F Differential (215°/205° F)* 250° F Manual Reset Fixed Max
Domestic Hot Water Tank	Tank Aquastat (On Tank)	Energy Kinetics PN: 10-0414	'Hot', pointer points to 6 pm. (To suit individual installation)

For legacy controls, contact Energy Kinetics

* Factory Setting

PREPARE FOR START UP

DANGER: MAKE CERTAIN THE FOLLOWING REQUIREMENTS HAVE BEEN SATISFIED BEFORE START UP:

1. The boiler and piping are completely filled with water.
2. Re-check wiring to ensure that it is correct and in accordance with appropriate wiring diagrams and codes.
3. Verify that proper gas orifice size is used.
4. Verify electrode and flame sense rod settings.
5. Verify the burner settings for air band position and head position (see "Gas Burner Settings" Table).
6. Gas supply is connected to burner. Gas supply lines and shut-off valves are open.
7. Gas lines are purged.
8. Verify operating gas pressure at inlet of gas valve.
9. Adjust bypass valve on boiler side of heat exchanger to half open (see #4 under "Gas Burner Operation").
10. Polypropylene flue pipe properly connected from unit to sidewall vent hood or chimney kit. All joints are secured and sealed with integrated gaskets – all interior connections must utilize lockrings.
11. Combustion air supply is available and sufficient. (See "Combustion Air")
12. **NOTICE:** Do not punch a hole in the polypropylene flue pipe.
13. Loosen both of the 1/8" plugs in front door of the boiler, one for use as the overfire sampling location and the other for the breech sampling location.

START UP PROCEDURE

Turn on system supply switch and burner supply switch. The Display Energy Manager lights should come on briefly, the circulator relay should close briefly, and then the Display Energy Manager will show a red light next to 'power' and yellow lights on the left side if any thermostats are calling.

1. If needed, adjust a thermostat to call for heat. Burner and main circulator should come on at the same time. If not, check primary control and reset it if necessary.
2. Check for burner light off. If gas piping is not well purged, then several starts may be required to clear air from gas piping.
3. On light off, water temperature and flue gas temperature will start to rise. A slight odor is common on initial light off as combustion chamber and converter surfaces warm for the first time.
4. **NOTICE:** Perform carbon monoxide test two minutes after light off. If the carbon monoxide exceeds 400 ppm *air-free* after two minutes of operation, shut off boiler immediately and repeat "Prepare for Start Up" checklist. (See "Air-free method of measuring CO")
5. Once the boiler heats up and reaches temperature, Display Energy Manager "Heating" light will signal heat distribution to zone(s) calling for heat.
6. Allow system to run about 15 minutes before testing and recording burner operation. (See "Gas Burner Operation")

The AIR-FREE METHOD of MEASURING CO

Air-free measurement of CO takes account of the amount of excess air by incorporating an adjustment to the as-measured ppm value, thus simulating air-free (oxygen-free) conditions in the combustion gases. To do this, a reading of oxygen (O₂) or carbon dioxide (CO₂) percentage is taken from the combustion gases along with the as-measured CO reading. This can be done with a meter having the capability of measuring CO *and* O₂ or CO₂ percentage, or it can be done with two different meters, one measuring CO ppm and one measuring O₂ or CO₂ percentage.

If air-free CO is determined with a single meter, an integral electronic chip calculates the air-free level from as-measured CO ppm and O₂ percentage.

If two meters are used, the equations below can be used to determine the air-free level of CO in a combustion gas sample.

For natural gas or LPG, using as-measured CO ppm and O₂ percentage:

$$CO\ AF_{ppm} = \left[\frac{20.9}{20.9 - O_2} \right] \times CO\ ppm$$

For LPG, using measured CO ppm and CO₂ percentage:

$$CO\ AF_{ppm} = \left[\frac{14}{CO_2} \right] \times CO\ ppm$$

For natural gas, using measured CO ppm and CO₂ percentage:

$$CO\ AF_{ppm} = \left[\frac{12.2}{CO_2} \right] \times CO\ ppm$$

Where:

CO AF_{ppm} = Carbon monoxide, air-free ppm

CO ppm = As-measured combustion gas carbon monoxide ppm

O₂ = Percentage of oxygen in combustion gas, as a percentage

CO₂ = Percentage of carbon dioxide in combustion gas, as a percentage

GAS BURNER OPERATION

NOTICE: For reliable operation, set Air-Fuel mixture conservatively based on installation conditions. Carbon dioxide, Oxygen, and Carbon Monoxide readings should be taken through 1/4" test port in front jacket opening just to right of burner (see FIG. 5A). Sample tube must extend at least six (6) inches into front cover to obtain accurate readings. A test port is provided for the flue box (see FIG. 5A) to measure draft loss.

NOTICE: For accurate efficiency calculations, measure flue gas temperature in flue box test port (top brass plug on front of boiler). Flue box and over fire temperatures may be higher than flue gas temperature measured in the flue pipe.

Installation Conditions	CO ₂ Setting	O ₂ Setting
Target for Normal Conditions	LPG: 10.4% NG: 9.0%	LPG: 5.0% NG: 5.0%
Operational Range	LPG: 8.4% to 13.1%* NG: 7.3% to 11.4%	LPG: 8% to 1.5% NG: 8% to 1.5%

* Although the Resolute RT boiler can operate without excessive CO below 4% O₂, the nominal gain in efficiency may not offset the potential of increased maintenance costs.


Note: CO₂/O₂ must be checked with air box cover in place.

AFTER 15 MINUTES RUNNING, CHECK AND RECORD:

- | | |
|--|---|
| 1. DRAFT AT OVER FIRE TEST PORT..... | Negative pressure |
| 2. CO ₂ /O ₂ | See table above |
| 3. STACK TEMPERATURE | 190° to 290° F |
| 4. CO TEST..... | Must be less than 400 ppm <i>air-free</i> |

1. **DANGER:** Verify proper operation of high limit aquastat:
 - a. Remove all heat and hot water calls (No input lights on left side of manager).
 - b. Turn System switch off, then remove red sensor lead from the left side quick connect.
 - c. Restore power. The display will flash "Error 100 Sensor Failure", and the burner should start momentarily.
 - d. At approximately 205° F to 215° F, the high limit aquastat should shut off burner.
2. **DANGER:** Verify proper operation of boiler pressure relief valve by following instructions on pressure relief valve, which calls for a 'try lever test'. Make sure discharge pipe is properly placed to safely contain discharge and open relief valve using the try lever.
3. **NOTICE:** Check that each thermostat operates proper zone.
4. **NOTICE:** Bypass valve must be adjusted to raise return water temperature to approximately 130° F. on start up after any zone valve opens. This prevents condensation from occurring in boiler passages. The Display Energy Manager provides condensing protection by closing the zone valves when the return drops below 130° F (Check option switches on the Display Energy Manager and verify that switch one (1) is set to "ON"). The following adjustments will help minimize zone cycling.
 - a. On copper baseboard systems, valve normally should be ½ open.
 - b. On large water volume systems or high heat load systems, where the return temperature from the system is below 130° F, open bypass completely and throttle zone returns to increase bypass flow.
5. **DANGER:** Verify flame failure lockout of Carlin 60200FRS burner control
 - a. Close the main manual gas valve and turn the combination gas valve knob to ON.
 - b. Turn on power to Resolute RT boiler and adjust a thermostat to call for heat.
 - c. Burner motor will start. The burner control will run for 30 seconds (pre-purge), and then start the ignitor. Approximately one second later, the combination gas valve will open.
 - d. After the Trial For Ignition (TFI) period of 4 seconds, the burner control will lockout display the lockout message. The ignitor will shut off and the gas valve will close.
 - e. If lockout does not occur, replace the burner control.
 - f. Turn on the main manual gas valve to restore operation.
6. **WARNING:** Blocked Vent or Dilution Air Exhaust Fan (inducer) Malfunction Test:
 - a. Remove power from the inducer. (Tip: turn off option switch 2 on the Display Energy Manager)
 - b. Start burner. Safety lockout should occur in approximately 1 minute.
 - c. Restore power to the inducer. (Tip: turn on option switch 2 on the Display Energy Manager)
7. **WARNING:** Blocked Air Intake Test:
 - a. Block the air inlet piping to the burner air box boiler at the PVC wye fitting.
 - b. Start the burner. The burner motor will not be powered and the primary control will cause a recycle or lockout within approximately 1 minute.
 - c. Unblock the air inlet piping and verify that the burner operates normally.

Energy Manager Operation



WARNING: Do Not Jump!

If you apply 24VAC to any Energy sensor lead with the sensor connected to the Manager, you will burn out both the sensor and the Manager in less than a second.

NOTE: The Manager cannot lockout the primary control on the burner. The E140 error code will usually indicate that a burner lockout has occurred.

Testing Manager Lights: To confirm operation of the Manager lights, turn power off briefly and power up the Manager. On startup, all output lights will turn on for a brief moment and LCD back light is turned on.

A) Thermostat Lights:

Indicate a thermostat calling for heat. If all lights are OFF, the burner will not run because there is no call for heat. T₄ is located on the bottom. SET HEAT ANTICIPATORS FOR 0.1 AMPS. There is a 25 second delay to prevent thermostat short cycling.

B) Return Temperature Thermistor:

Senses return temperature and is required for manager to work properly. If the thermistor has failed, the E100 error code is displayed for the first ten minutes. After ten minutes, the manager switches to and displays E190 error code (Classic Mode). Disconnecting the RED lead will cause the manager to run in these modes also.

C) Option Switches:

Set option switch 1 to **ON** for systems with a gas burner. Set option switch 2 to **ON** for sidewall vent systems.

D) LCD Display:

Displays boiler RETURN temperature, not supply temperature.

- The Manager is the **operating aquastat** and will turn off the burner if **return** temperature reaches 170°F (operating limit).
- The zone outputs will open when the return temperature is above 140°F and close zone outputs when the return temperature drops below 120°F. If a new zone calls when the returns are below 140°F the new zone will not open until the temperature exceeds 140°F (even if other zones are open).
- The boiler will typically take about 2 minutes to reach 140°F from a cold start.

When the Manager is working properly and has found a condition that needs service, the E100, E130, E140, E150 or E190 error codes will be displayed along with a description of what the error code means. See page 27.

E) Heating or Zone Lights:

Indicate 24-volt power from 24VAC to Z_x (Z_{HW}, Z₁, Z₂, Z₃, and Z₄). This provides power to 24-volt zone valves or zone circulator relays. **NEVER JUMPER THIS CONNECTION!**

F) Inducer (Dilution Air Exhaust Fan) Light On:

Indicates 24 volts from IND to 24VAC. This pulls in the 24-volt coil on the inducer (IND) relay, providing 120-volts to the power vent. *This will only operate with option switch 2 ON.*

G) Burner Light On:

Indicates a closed contact between B₁ to B₂. This is wired to T-T on the burner primary control.

H) Circulator Light:

On indicates 24 volts from manager CIRC to manager 24VAC. This pulls in the 24-volt coil on the Burner/Main circulator relay, providing 120-volt power to both the main circulator and the burner.

Energy Manager Check

Troubleshooting

The burner will not run unless there is a call for heat (thermostat call) or a call for domestic hot water (tank aquastat).

Note: Do **NOT** Jumper Connections or Apply Voltage to Test the Manager.

Follow these simple steps:

1. Look at the Manager
2. See what it is telling you is supposed to be happening.
3. See if it is happening, and if it is not, find out why (see below).
4. If you do not find the problem, perform the 2 Minute Energy Manager Diagnostic to check all Manager functions.

These are the thermostat input lights. These lights indicate when a thermostat is calling and only come on when there is an external connection.

- If the light is not ON, check the thermostat and thermostat wiring.
- If the light is ON, the thermostat is calling.

This is the LCD display.

- If no alerts are present, the display will show the *operation mode* and the *return temperature*.
- If an alert is detected, it will be displayed here, along with brief diagnostic or informational details.

These are zone output lights.


- If the light is ON, the zone valve should be open. For hot water, the bronze circulator should be running.
- If zone valve is not open with the light on, check the zone valve and zone valve wiring. For hot water, check the hot water relay, wiring, and the bronze circulator.

This is the power vent inducer output. This light should only operate if dip switch 2 is on.

- If the light is ON, the inducer should be running.
- If the light is on and the inducer is not running, check the inducer, wiring, and inducer relay and wiring.

This is the burner output. This light indicates T-T is made on the burner.

- If the light is ON, the burner should be running.
- If the light is on and the burner is not running, check the burner, limit aquastat, wiring, burner/main circulator relay, and burner service switch.



Remember:

- 1) Most 'no heat' problems are **not** caused by the Manager.
- 2) The Manager **cannot** cause a burner lockout.

2-Minute Energy Manager Diagnostic

Most no-heat problems are not caused by the manager. Perform this test to prove proper manager function. Do **NOT** replace the manager if it functions properly in these tests.

The manager cannot cause a burner lockout.

Step 1:

Make sure you have no thermostat calls (turn thermostats down or disconnect after labeling zones).

Step 2:

Turn Service Switch OFF for 5 seconds.


Turn Service Switch ON while carefully observing the display.

The display should briefly show "Startup Selftest", before changing to show the manager mode and return temperature.

The BLUE power light will remain ON whenever the board is powered.*

This proves the following:

- The display works
- The board is able to detect the board type and mode
- The processor is functioning properly



Step 3:


Turn Service Switch OFF for 5 seconds.

Turn Service Switch ON while carefully observing the output lights. The output lights should all turn on for about a second, and then turn OFF.

The BLUE power light will remain ON whenever the board is powered.*

This proves the following:

- All the output lights work
- 24 VAC should be present
- The processor is functioning properly (second verification)



*If you observe problems in step 2 or step 3, turn Burner Service Switch OFF, disconnect the right hand (output) quick-connector and repeat steps 1, 2, and 3. If problem persists, call technical support or replace manager. Note malfunction on warranty tag and return manager to Energy Kinetics. If problem goes away, there is a problem with the output wiring – check all wiring, re-connect quick-connector and repeat steps 1, 2 and 3 until problem is resolved.

You're done. The manager is functioning properly. Remember to reset thermostats to original set point, to re-connect wiring connections, connect the quick-connector and to turn the Service Switch ON

Additional Manager Tests

Perform the following tests ONLY if you have any of the following:

Case 1) Zones heating intermittently

Case 2) E140 or E150 displayed WITHOUT a burner lockout

Case 3) E100 or E190 displayed

If you have a burner lockout, troubleshoot as any conventional burner lockout.

Case 1: Zones heating intermittently

Step 1: Have all connected thermostats including hot water aquastat call continuously for at least 10 minutes. Service Switch must be ON. Turn burner switch off to prevent zone overheating and to maintain thermostat calls continuously.

Step 2: Observe thermostat Lights.

- If any thermostat input lights (left side) are not ON, check wiring and thermostats.
- If thermostat input light (left side) is OFF within 10 minutes, and with thermostat call present, thermostat input LED is bad. **Solution:** Move thermostat wire lead and zone valve wire lead to a different zone or replace manager.

Case 2: E140 or E150 alert without burner lockout

Step 1: Turn service switch OFF and disconnect right hand (output) quick-connector.

Step 2: Using a multi-meter, check the resistance from B1 to B2 on the manager solder strips. This will be an open circuit (infinite resistance).

Step 3: Turn service switch ON and start a thermostat call while observing the resistance from B1 to B2. Burner light should come on.

- If resistance is less than 3 ohms, manager is functioning properly. Look elsewhere for a problem.
- If resistance is greater than 3 ohms after 3 seconds of operation, B1-B2 contact is bad. **Solution:** Replace manager.

Case 3: E100 or E190 alert without burner lockout

Step 1: Check the sensor wiring and quick-connectors to ensure proper contact. To improve contact, remove and squeeze the plastic quick connect at all terminals with flat pliers so the gap just closes.

Step 2: Replace sensor if no wiring or quick-connector issues are identified.

Display Manager Return Sensor (Thermistor) Testing

The temperature sensor in the return line allows better boiler control, and virtually eliminates condensation caused by cold returns.

The temperature sensor is a thermistor sealed with epoxy inside a stainless steel well. The thermistor communicates continuously with the Manager thousands of times a minute.

The Display Manager is the tester of the display manager thermistor. It verifies that it is connected and working properly, if not, will either say "Sensor Fault, Replace Soon", indicating that one pair is bad or display the E100 or E190 error code.

- *The thermistor can be tested with an ohm meter, at room temp (approx. 77F) it should read ~10K Ohms between the black and red wires and between the white and red wires. As long as one pair is good, the manager will read the correct return temperature but display the "Sensor Fault, Replace Soon" message.*
- *Never connect 24 volts to the black, white or red sensor terminals (labeled B, S, or R.)*
- *A caution: T4 thermostat input is adjacent to R, the red sensor terminal. When making thermostat connections, never do so with power on.*
- *Once firm proper connections have been made, power up.*

WARNING: Do Not Jump!

To test the functioning of each output zone, never apply a jumper to the Energy Manager output terminals. The easiest way to test each zone output is to remove the red sensor lead. The Manager should go into Service Board Mode (E100) for 10 minutes, followed by Classic Manager Mode (E190). Adjust each thermostat to call for heat and the corresponding zone should come on if working properly.

Rule #1: Never use a jumper to test the function of the Energy Manager.

Rule #2: Never use a jumper to test the function of the Return Sensor.

Rule #3: Never use a jumper to test the zones outputs.

Rule #4: Only use a jumper from A1 to the thermostat inputs, if you can't reach the thermostats.

Line Voltage Relays

Remember that behind the Manager is the junction box with the line voltage relays. The line voltage relays are controlled by the Manager.

The burner and circulator power is controlled by one line voltage relay. If both burner and circulator are without power, check the relay.

If the domestic hot water circulator does not have power, check the hot water relay.

If equipped with an Dilution Air Exhaust Fan (inducer) and the fan does not have power, check the inducer (IND) relay. Also check to be sure dip switch #2 is turned "on".

Line Voltage

Resolute RT requires 120 VAC. The supply voltage must be within 108 VAC min / 132 VAC max for reliable operation of the boiler and the Manager. An easy way to check the supply voltage is to plug a volt meter in at the service outlet located on the system junction box.

Surge Suppression

The Relay Board located in the system junction box is equipped with built-in surge suppression on the 120VAC circuit. Older systems can be retrofitted using a plug-in surge suppressor.

TROUBLESHOOTING with the ENERGY MANAGER

Display Manager Error Codes and Faults

An error code on the display indicates that Display Manager has detected a problem.

- E100:** Temperature sensor is not working properly. This indicates that the Manager is in service board mode. **Circulator and Dilution Air Exhaust Fan (inducer) run constantly**, burner runs off the high limit aquastat. All inputs turn on respective outputs. If the sensor is not detected within ten minutes, the Manager will change to E190 mode.
- E190:** After ten minutes in E100 mode the Display Manager switches to E190 mode. This indicates that the Manager is operating in Classic Manager Mode. The boiler will operate as **cold start** instead of maintaining temperature as when in service board mode. When a thermostat calls, the system will **pre-heat** for two minutes before opening the zone output and will **post purge** for whatever the zone's max purge time is set.
- Check Sensor wiring. *Check sensor leads for loose connections or damage. If connections and wiring look good, **replace the sensor**.*
If Manager is left in this mode, set Dual Guard high limit to "Service Mode".
- E130:** Excessive temperature condition. Zones could not extract heat from boiler. *Check zone valves, heat exchanger and boiler circulation. High limit aquastat may not be functioning.*
- E140:** Boiler is in Freeze Protection Mode, Burner light off, Circulator light on, Heating zone outputs on. This means that the boiler return temperature did not increase enough to open zones within 27 minutes.

Does Primary Control need to be reset?

YES: Troubleshoot as standard burner lockout.

NO: Did homeowner reset control?

YES: Troubleshoot as standard burner lockout.

NO: Reset Manager. Run through standard heat cycle.

Does boiler return heat up properly?

NO: Check circulator. Possible closed or blocked bypass. Look for a zone valve not holding.

YES: Intermittent problem. Check low voltage wiring for tightness from Manager through relay board and cad cell relay to TT. Check line voltage at burner, in and out of cad cell relay. Check LWCO, Check limit aquastat for proper operation. See if burner/main circulator relay is properly plugged in and working properly.

- E150:** The return temperature did not reach 100°F after seven minutes. The manager will pulse the output of the calling zone for one minute on and one minute off. If the return increases within 20 minutes, the system will continue to run and supply heat while displaying the E150 code, indicating a boiler side blockage and that the manager is operating in Classic Manager Mode. When a thermostat calls, the system will pre-heat for two minutes before opening the zone output and will post purge for whatever the zone max purge time is set. If after 20 minutes the return does not heat up, the Manager will change to E140 mode.

Sensor Fault: On power-up, or display wake-up, the display will briefly show the message: "**Sensor Fault; Replace Soon**". This indicates that one of the two dual thermistors is giving an invalid reading. Check to ensure that all thermistor leads are securely connected and tightened on the left-hand side quick-connect. If the connections are secure, and the message is still displayed on power-up or display wake-up, the thermistor should be replaced.

TO RESET MANAGER

The Manager can be reset to normal operation by turning the system switch off and back on.

WARNING: **Do Not Jump!** If you apply 24VAC to any temperature sensor lead with the sensor connected to the Manager, you will burn out both the sensor and the Manager in less than a second.

OPERATION WITHOUT the ENERGY MANAGER

SERVICE BOARD MODE:

The Display Manager can be placed into “E100 (SERVICE BOARD)/E190 (CLASSIC MANAGER MODE)” by turning off the system switch and removing the RED temperature sensor lead from the left side input connector, and turning power back on. Removing the RED lead is similar to inserting the traditional green “Service Board”. The traditional service board may still be used if desired. E100 (SERVICE BOARD) allows the boiler to run like a conventional boiler for the first ten minutes. After which, it will switch to the E190 (CLASSIC MANAGER MODE). In CLASSIC MANAGER MODE, instead of maintaining temperature, the system will operate as the original “Classic” manager did. The burner will only run during a call for heat, pre-heat for 90 seconds, and post purge to the last zone(s) calling based on time instead of temperature and time.

TEMPORARY OPERATION WITH JUMPERS WHEN SPECIFIC OUTPUT NOT FUNCTIONING

(With partially functional Manager still in place and without service board)

If a particular function of the Manager fails, use appropriate jumper action below *with Manager in place*.

BURNER (B1-B2 CONTACT NOT CLOSING WHEN BURNER LIGHT IS ON): Jumper BB or TT on burner control. Burner will run on limit aquastat whenever Manager calls circulator. Zones may overheat slightly during energy recovery. Temporarily reset limit aquastat to 165°F/180°F.

MAIN CIRCULATOR (CIRC OUTPUT NOT FUNCTIONING WHEN CIRC LIGHT IS ON): Remove blue CIRC lead from right side and connect to A2 on the left side, using an extension lead. The circulator will run constantly and the burner runs on Manager call.

ZONE/HOT WATER CONTROL (ZONE VALVE OUTPUT NO FUNCTIONING): Move the thermostat and zone valve to an open functioning zone. If no open zone is available, move the zone valve lead to the output of another zone with similar calling patterns. For example if Z2 output is not functioning, move the zone valve wire from Z2 to Z3; zone 3 (Z3) will power both zone valve 2 and zone valve 3 simultaneously. *Note that heat motor zone valves power requirements exceed the capacity of the manager zone output (similar to a short) and an auto-resettable fuse will turn off the zone until the excessive load is removed. Heat motor zone valves including Taco Gold and Green 500 series valves should be replaced with Erie/Schneider, Honeywell, Caleffi, or other 24 VAC full port, fast acting, low power consumption valves.*

IF A RELAY ON THE RELAY BOARD FAILS: Rewire to the included spare relay. If spare is not available, install a relay with 24VAC coil and 120VAC contacts. For emergency heat when the BURN/CIRC relay is not functioning, you may temporarily install a 120VAC jumper on the relay board from PWR to BURN. The main circulator will run constantly and the burner will only run when the Burner output light on the manager is ON. This does not bypass any safety controls.

EMERGENCY HEAT WITHOUT ENERGY MANAGER or RELAY BOARD

(Temporary Operation Only – 5 minute wiring change)


Method A (Heat and Hot Water):

If the relay board is functioning properly, install a service board or follow the wiring instructions in the Owner and Installation Manual to run without a manager.


Method B (Heat Only) – Temporarily relocate (3) wires shown by arrows:

- 1) Move the black 120VAC wire from PWR to BURN (shown below).

This will apply power continuously to the main circulator which will circulate water throughout all of the open heating zone valves. The stairway switch may be used to stop the circulator (and Dilution Air Exhaust / Inducer Fan) if desired.



Relay board



- 2) Select **one** thermostat that will control when the boiler runs to add heat to the house. Move that representative thermostat (T1, T2, T3, or T4) from the left side of the manager to B1. Move the other wire from that thermostat from A1 to B2. *B1 and B2 connect internally to TT on the burner.*
- 3) Turn down the high limit aquastat to 165°F/180°F and test and confirm proper and safe function. *When returning to service, reset high limit to 205°F/215°F.
- 4) Manually open all desired zone valves and close return valve a bit.

There will not be any condensing protection without the manager; closing the return a bit will help limit condensing of flue gases.

NOTE for sidewall vent systems: Add a 120VAC jumper from BURN to IND. This will run the Dilution Air Exhaust Fan (inducer) continuously, so caution should be used in systems without antifreeze.

TROUBLESHOOTING THE SAFETY PRESSURE SWITCHES

The Resolute RT has three separate pressure switches to ensure safe operation in the event of several possible failure conditions. A blocked vent switch measures the over-fire pressure to ensure the boiler maintains negative pressure before the Dilution Air Exhaust Fan (inducer), a fan prover switch ensures the dilution air blower is operating when the burner is firing, and a blocked intake switch ensures the fresh air intake has not become obstructed. The blocked vent (puff) switch is connected to the 'BV' terminals on the burner primary control, while the fan-prover and blocked intake switches are connected in series with the gas valve transformer at the primary control.


If the 'BV' terminal is an open circuit, the blocked vent switch has opened, and the burner will recycle and eventually lockout. Measure the pressure at the overfire test tee and ensure the boiler is operating at negative pressure. If the switch remains open despite continuous negative pressure overfire, replace the switch.

If the burner fails to prove flame (resulting in a lockout), it is likely that the blocked intake normally-closed switch has opened, or the normally-open Dilution Air Exhaust Fan prover switch has failed to close. By process of elimination, which switch is causing the lockout may be quickly determined.

The blocked intake switch can be disabled by removing the flex tubing on the Dilution Air Exhaust Fan (inducer) assembly that connects it to the pressure tap (it is not required to remove the switch housing to remove this tube). After removing the tube, run the burner and check for power to the gas valve. Attach a monometer to the plastic nipple that the flex tubing was attached to. The intake must not be more negative than -1.00" w.c. of vacuum (-0.50 to -0.85" w.c. is typical). If the intake is showing high vacuum (and the burner now runs with the switch disabled), check for signs of a blockage in the intake and ensure that the intake length is shorter than 50' (with each elbow counting as 5' equivalent length).

The final switch to check is the normally-open Dilution Air Exhaust Fan proving switch. Check for voltage at the gas valve. Once the dilution-air blower turns on (and the primary control has entered TFI), the circuit should be powered with 24VAC at the gas valve (120VAC on the violet wire at the primary control). If the dilution air blower fails to turn on, ensure there is power reaching the Molex connector on the blower assembly. If the inducer fan is running and gas valve is not powered, bypass the switches to confirm the burner proves flame with just the gas valve transformer in the circuit. If the circuit now proves, replace the switch, if not, gas valve or gas valve transformer. Place the safety switches back into the gas valve transformer circuit to resume normal operation.

NOTE the Dilution Air Exhaust Fan (inducer) will not prove if there is no venting attached; an elbow or a short length of pipe is required to provide adequate backpressure to close the fan-prover switch.



ANNUAL TUNE UP & INSPECTION

Step 1 Initial Test (Draft Test & CO₂)

Air box cover must be in place before testing.

1. Remove 1/8" brass plug flue box test port (1) next to the puff switch. Check draft through the flue box (1) using 12" long piece of 1/4" O.D. steel or copper tubing inserted approximately 8" into the boiler. Connect this tube to your test probe using a piece of hose.

Draft must be negative.

2. Check CO₂ through the over fire test port (2). Insert the 12" long steel or copper tube approximately 8" in through the test port.

LPG Target CO₂: 10.4% Target O₂: 5.0%
NAT. Target CO₂: 9.0% Target O₂: 5.0%



Electronic Analyzer

Step 2 Open Front Cover

Turn off power to system and close main manual gas valve when servicing.

1. Loosen, but **DO NOT REMOVE** (2) lower nylock nuts on hinge bolts.
2. Remove (3) upper nuts and support cover while opening.

Step 3 Inspect Flue Passage and Vent System

If passage is clean, no scale, then proceed to step 5.


Clean ONLY if dirty.

Check vent system joints for proper connections, including flexible coupling clamps and condensate drain.

Step 4 Clean Boiler

Note: If there is evidence of condensing in last pass:
If cold returns:

1. Verify Display Manager Option Switch 1 to "ON".
2. Open by-pass valve fully.
3. If condensing persists, increase firing rate.



Drawer Assembly

Step 5 Remove Drawer Assembly



(Refer to burner manual for detailed instructions on removal and for burners other than EZ-Gas)

1. Close the front cover and finger tighten a nut on the top center stud to hold the cover closed while working on the burner. Do not tighten the rest of the nuts at this time because you will need to open the cover up again to check the drawer assembly to the diffuser plate.
2. Check porcelain condition.
3. Check and clean flame sense rod.

Step 6 Check Burner

(Refer to burner manual for complete details and for burners other than EZ-Gas)

1. Check Fan/Air Inlet for dirt or lint.
2. Install drawer assembly carefully lining up the ignitor electrode and flame sense rod. Open the front cover and check, neither should be any closer to the diffuser plate than 1/16". Adjust if necessary.
3. Check amulet for cracking or other physical damage. Replace if necessary. (See amulet replacement section in installation manual).
4. Check burner diffuser plate. Some warping of plate is normal as long as it does not interfere with the operation of the burner.





Flame Sense Rod
Tip should extend
in front of diffuser
by 1-1/4".

Ignitor Electrode
Tip should be set
back 1/16" from the
inside surface of
diffuser.

Diffuser Plate

**Note: All burners require
"Amulet" retention head
protector.**



Digital Manometer



Step 7 Close Front Cover, Tighten Rear Cover

1. Install (4) upper nuts and washers.
2. Tighten nuts (6) uniformly.
3. Check and tighten (6) rear cover nuts.
4. Check Flue Pipe.

Step 8 Check Zone Valves

Open/Close zone valves several times to see that they move freely.

Step 9 Backflush Plate Heat Exchanger

1. Close the valve underneath the domestic hot water circulator.
2. Open drain valve above the circulator to back flush the heat exchanger.
3. If domestic water supply is "hard" (lime), consider installing Scale Stopper (Item no. 10-0650).
4. Set temperature feeding hot water tank (above heat exchanger) by adjusting the ball valve below the bronze circulator. Adjust the ball valve with the burner running and a continuous flow of hot water from a fixture. You should just be able to hold your hand on the pipe.

Step 10 Start Burner & Check Safety Functions

Check & Record: Air box cover must be in place before testing.

Refer to burner manual for recommended settings.

1. Check manifold pressure by installing a hose barb fitting in the combination gas valve outlet pressure tap and then starting the burner. Adjust valve regulator if necessary so the reading is 3.5" w.c. for either LPG or natural gas.
2. Draft Test: Draft must be negative in the flue box port (1).
3. Check CO₂/O₂ at over fire test port (2) Nat. Gas: CO₂ :9.0%, O₂ :5.0% Nominal
LPG: CO₂ :10.4%, O₂ : 5.0% Nominal
4. Stack Temp: 190°-290° F at flue box port (1).
5. Check CO: 400 ppm Max *Air-free*
(Refer to installation manual for *Air-free* method of measuring CO).
6. Set Safety DualGard High Limit to 215 °F with Differential set at 10°F.
7. Test Safety High Limit Aquastat:
 - a. Remove all heat and hot water calls (No input lights on left side of manager).
 - b. Turn System switch off, then remove red sensor lead from the left side quick connect.
 - c. Restore power. The 100° light will flash on the manager's temperature display. The burner should start momentarily.
 - d. At approximately 205°F to 215°F, the high limit aquastat should shut off burner.
8. Verify flame failure lockout of Carlin 60200FRS burner control.
 - a. Connect hose from manometer to hose barb fitting in the combination gas valve outlet pressure tap.
 - b. Close the main manual gas valve and turn ON the combination gas valve.
 - c. Turn on power to Resolute RT boiler and adjust a thermostat to call for heat.
 - d. Burner motor will start. The burner control will run for 30 seconds (pre-purge) and then start the ignitor. Approximately one second later, the combination gas valve will open. The manometer should show almost no pressure because the main manual gas valve is closed.
 - e. After 4 seconds, the burner control will lockout and turn on the red LED. The ignitor will shut off and the gas valve will close. Turn off power and adjust the thermostat to stop the call for heat.
9. If lockout does not occur, replace the burner control.
9. Dilution Air Exhaust Fan Safety Switch test:
 - a. Remove power from the inducer by turning Display Energy Manager Option Switch 2 OFF.
 - b. Start burner. Safety lock-out should occur in approximately just over 30 seconds.
 - c. Restore power to the inducer by turning Option Switch 2 ON and reset burner lockout.

ORDERING REPLACEMENT PARTS

To order replacement parts, specify serial number stamped onto nameplate, part description and part number from parts list and assembly drawing on the next page.

AMULET REPLACEMENT

It is recommended that a new ceramic sleeve “amulet” be installed each time the air tube is removed from unit. See instructions that come with each amulet. The Resolute amulet is larger than the standard amulet, so be sure to order the proper part number shown in the Assembly Drawing. Using a standard amulet will allow excessive heat back to the front jacket and may damage burner tube.

COMBUSTION CHAMBER REPLACEMENT

The combustion chamber is of stainless steel super-alloy material and will normally not need to be replaced.

A replacement chamber, if required, is available from Energy Kinetics.

The proper part number for the Resolute stainless steel chamber must be specified when ordering. For interim operation, the unit may be run without a combustion chamber if necessary. Ensure that the burner head is protected by the amulet, wet pack or a similar material.

WARNING: Ceramic fiber or fiberglass materials, may contain carcinogenic particles (cristobalite) after exposure to heat. Airborne particles from fiberglass or ceramic fiber components have been listed as having potential health effects. Take the following precautions when removing, replacing and handling these items.

Precautionary procedures:

Avoid breathing dust and avoid contact with skin or eyes. Wear long-sleeved, loose-fitting clothing, gloves and eye protection. Use a properly fitted NIOSH certified respirator for dusty activities and where exposure levels are unknown.

Use hand tools whenever possible if cutting or trimming is required. Power tools generate significantly more airborne dust.

Use vacuums with HEPA-filters for clean up. If HEPA-filter vacuum are not feasible, lightly spray fiber materials and work area with a water mist before sweeping or bagging of debris.

Wash exposed skin with soap and water after handling.


Do not use compressed air to clean work clothes or work area.

Wash work clothes separately from other clothing. Rinse washer thoroughly afterwards.

Avoid smoking, eating or drinking while dust is present in the work area.

REPLACEMENT PARTS

Obtain replacement parts from your local Energy Kinetics dealer.
Contact Energy Kinetics at 800-323-2066 or www.energykinetics.com
for help locating your nearest authorized dealer.



ITEM	EK1T PART NO.	DESCRIPTION	ITEM	EK1T PART NO.	DESCRIPTION
A	10-0828	Combustion Chamber (Stainless)	L	10-0830	Rear Insulation Board 2"
B	10-0825-P	Energy Converter	M	10-0826-B	Rear Cover
C	10-0831	Front Liner Board	N	10-0833	Front Board Clip (ea)
D	10-0832	Rear Liner Board (PacMan)	P	10-0726	Door Hinge Assembly (ea.)
F	10-0829	Front Insulation Board 2"	R	10-0827-RL	Base Right Leg
G	10-0826-F	Front Cover	S	10-0827-LL	Base Left-Leg
H	10-0826	Left & Right Side Jacket	T	10-0827-FP	Base Front/Rear Panel (ea)
J	10-0826-JB	Junction Box	U	10-0295	Power Vent Assembly
K1	10-0826-TR	Top Right Jacket	V	10-0296	Vent Adaptor
K2	10-0826-TL	Top Left Jacket	W	10-1064	Vent Adaptor to PPS
K3	10-0826-MGR	Top Front Jacket	X	10-1700-AB	Silent Air Box Kit

COMMON ITEMS AVAILABLE BUT NOT SHOWN

PART NO.	DESCRIPTION
10-0434H	Air Vent, 1/2" with 3/4" bushing
10-0178	Puff Switch
10-0596	DualGard w/Sensor w/o Well
10-0597	DualGard Well, 1/2" NPT
10-0568F	TACO 007e ECM Circulator
10-0705	Amulet Carlin EZ1
10-0150	3/4" Two Wire Zone Valve (Std)
10-0151	3/4" Four Wire Zone Valve (w/End Switch)
10-0418B	5 Zone Display Manager

PART NO.	DESCRIPTION
10-0496-C	EZ-Gas Primary Control
10-0420	T&P Gauge
10-0933	Cartridge for Smart Filter
10-0496-GV	24V Gas Valve
10-0496-D	Drawer Assembly
10-0416	#14 Plate Heat Exchanger w/Unions
10-0516	Boiler Pressure Relief Valve 30 psi
10-0417T-18	Aquastat: Thermistor for use with Display Manager
10-0412B	Printed Relay Board w/4 Soldered Relays

Resolute™ RT

HIGH EFFICIENCY BOILER by ENERGY KINETICS

LIFETIME LIMITED WARRANTY For Residential Water Boilers

By this Warranty Statement, Energy Kinetics, Inc. of Clinton Township, New Jersey, issues limited warranties subject to terms, conditions, exceptions and exclusions listed below.

These Warranties are issued only to the person or entity which owns the building in which the boiler is installed at the time of original installation and only for such portion of the warranty periods as such person or entity owns such building (hereinafter, the "End User").

I. THREE YEAR – LIMITED WARRANTY FOR RESIDENTIAL WATER BOILERS

Energy Kinetics warrants that its residential heating Resolute RT, with residential water boiler, is free from defects in material and workmanship for three years from the date of installation. If any parts are found to be defective in manufacture, Energy Kinetics will repair or replace the defective parts. Exception: Honeywell Zone Valves

II. ADDITIONAL COMPONENT LIMITED WARRANTIES

1. Energy Kinetics warrants that its Display Energy Manager is free from defects in material and workmanship for a period of five years from the date of installation. The warranty is extended to the End User for the lifetime of the unit by a manufacturer sponsored rebuild program offered at nominal cost.
2. Energy Kinetics hereby assigns to the End User limited warranties of the original manufacture of components supplied by Energy Kinetics to the extent or duration assignable.
3. If any such component is found defective, Energy Kinetics' responsibility is solely to repair or replace the defective part at it's or the original manufacturer's option.

LIFETIME LIMITED WARRANTY FOR THE PRESSURE VESSEL

During the lifetime of the original owner in the original place of installation, Energy Kinetics warrants that those parts, which comprise the pressure vessel of the residential hot water boiler, remain free of defects in material or workmanship under normal usage.

In the event that such pressure vessel is found to be defective in material or workmanship during the first 10 years, Energy Kinetics will repair or replace the pressure vessel at its option and include a labor allowance per the published schedule. After 10 years, there will be a proportionate charge based upon the time the defective assembly was in service. The proportionate charge will be equal to the appropriate percentage of the trade list price of such pressure vessel at the time the warranty claim is made as determined in the following:

YEAR:	1 st	11 th	12 th	13 th	14 th	15 th	16 th	17 th
	Percent of Trade list Price:							
	0%	5%	10%	15%	20%	25%	30%	35%
YEAR:	18 th	19 th	20 th	21 st	22 nd	23 rd	24 th	25 th
	Percent of Trade list Price:							
	40%	45%	50%	55%	60%	65%	70%	75%
YEAR:	25 TH and Above: 75% of Trade list Price							

IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY-ENERGY KINETICS EXPRESSLY DISCLAIMS AND EXCLUDES ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY.

This Warranty gives you specific legal rights and you may have, also, other rights which vary from state to state.

EXCEPTIONS AND EXCLUSIONS

1. The warranty is subject to the condition that the residential boiler must have been installed and serviced in accordance with Energy Kinetics instructions, the basic BOCA Building Code, local statutes and ordinances and accepted good industry practice.
2. This warranty does not cover components that are part of the heating system but which were not furnished by Energy Kinetics.
3. This warranty does not cover the workmanship of any installer of Energy Kinetics residential water boiler. In addition, it does not assume any liability of any nature for unsatisfactory performance caused by improper installation.
4. This warranty does not cover improper burner adjustments, control settings, care or maintenance.
5. This warranty does not cover any labor for removal or reinstallation of the alleged defective part, transportation to Energy Kinetics if necessary and other materials necessary to perform the exchange.
6. This warranty does not cover failure of the pressure vessel other than defects in material or workmanship and shall specifically exclude any other reason including but not limited to a) lack of water b) freezing c) excessive pressure d) floods e) fire f) acts of God g) corrosion of internal or fireside surfaces h) improper water conditioning i) improper maintenance of external fireside surfaces j) operation with defective fuels or other additives which cause deposits to collect or corrosion to occur in or on the pressure vessel.



LIFETIME LIMITED WARRANTY (Continued from Previous Page)

7. Systems installed with chimneyless, through the wall venting option may have less than complete or poor combustion which may cause sooty fumes, odors or gradual discoloration of the area near the vent (exhaust) outlet. Poor combustion is generally the result of a burner being out of adjustment for a number of reasons, including but not limited to fuel condition and combustion air supply. Energy Kinetics does not guarantee nor warranty that all times the exhaust contents will be without a trace of soot or odor for reasons described above. Periodic cleaning and repainting of the area around the vent hood may be required if the appearance is objectionable in the view of the end user. Such cleaning or repainting is not the responsibility of the service company, installer or manufacturer.

WARRANTY TRANSFER

By completion of the Warranty Transfer Agreement, the original owner may transfer the warranty to a new owner by payment of a \$75 registration fee.

WARRANTY SERVICE

For prompt warranty service, notify the installer who in turn will notify Energy Kinetics that the purchaser believes there is a defect in material or workmanship covered by this warranty statement.

If within 30 days of the discovery, this action does not produce a prompt response, notify Energy Kinetics, Inc. 51 Molasses Hill Road, Lebanon, NJ 08833, in writing with details to support the warranty claim.

The End User is required to make available for inspection by Energy Kinetics or its representative, the parts claimed to be defective and, if requested by Energy Kinetics, to ship said parts prepaid to Energy Kinetics at the above address for inspection or repair. In addition, the homeowner agrees to make all reasonable efforts to settle any disagreement arising in connection with this claim before resorting to legal remedies in courts. If you have any questions about the coverage of this warranty, contact Energy Kinetics at the above address.

Lifetime Limited Warranty Transfer Agreement

(I/We), the undersigned, as the original purchaser of the **Resolute RT** home heating system, submitted the *Warranty Registration* within three (3) months of installation of (my/our) **Resolute RT** to Energy Kinetics, Inc., and (I/we) hereby transfer our Lifetime Limited Warranty to the new owner(s) of the home located as noted below. Warranty coverage begins on the date of original installation.

Resolute RT Serial Number: _____ **Date of Original Installation:** _____

Name of original purchaser of **Resolute RT**: _____
Print or Type full Name(s)

Located at this street address: _____

City: _____ State: _____ Zip: _____

TRANSFER TITLE of ENERGY KINETICS' WARRANTY TO: _____

Print or Type full Name(s)

New Owner(s) of the **Resolute RT** located at the address noted above. Title to be effective, _____
and continues uninterrupted coverage as is left on the original warranty. Enter Date
of Title Transfer

(Example: If the original owner has used 9 years, 3 months and 10 days of the warranty, the new homeowner warranty transfer begins at 9 years, 3 months and 11 days and continues to the end of the warranty as described on the back of this agreement or until the new homeowner sells the residence).

Enclosed is a check for \$75.00 to register and maintain the warranty as described on the back of this Warranty Transfer Agreement to the new homeowner named above. Please make check payable to Energy Kinetics, Inc.

Agreed to by the Original Homeowner: _____ Accepted: _____
Original Homeowner Signature New Homeowner Signature

***** For Office Use Only *****

Energy Kinetics, Inc. Received Transfer Information: _____ \$75.00 Received _____ Check No. _____
Date Received and Registered

Confirmation of Transfer mailed to New Homeowner: _____ By: _____
Date Office Personnel